Comp4621 Wireshark labs: TCP and UDP

TA: Waheed Ghali

E-mail: wggghali@connect.ust.hk

Outline

- TCP
 - Review of TCP
 - Capturing a bulk TCP transfer from your computer to a remote server
 - A first look at the captured trace
 - TCP Basics: 3-way handshake, RTT
 - Plot graphs

- UDP
 - Review of UDP
 - UDP basics

TCP: Review of TCP

- TCP: reliable, in-order delivery
- Sequence numbers: byte stream "number" of first byte in segment's data
- Acknowledgements: sequence number of next byte expected from other side (cumulative ACK)
- Setting TCP timeout value: based on estimation of RTT by exponential moving average of sampled RTTs
- Establish connection via 3-way handshake: client sends SYN message, server sends SYNACK message, client sends ACK message
- Flow Control: receiver notifies free buffer space through 'rwnd' value in TCP header, for which sender limits 'in-flight' data

TCP: Capturing a bulk TCP transfer from your computer to a remote server

- Start up your web browser. Go to <u>http://gaia.cs.umass.edu/wireshark-labs/alice.txt</u> and retrieve an ASCII copy of Alice in Wonderland. Store this file somewhere on your computer.
- 2. Go to http://gaia.cs.umass.edu/wireshark-labs/TCP-wireshark-file1.html

Upload page for TCP Wireshark Lab Computer Networking: A Top Down Approach, 6th edition Copyright 2012 J.F. Kurose and K.W. Ross, All Rights Reserved

If you have followed the instructions for the TCP Wireshark Lab, you have already downloaded an ASCII copy of Alice and Wonderland from http://gaia.cs.umass.edu/wireshark-labs/alice.txt and you also already have the Wireshark packet sniffer running and capturing packets on your computer.

Click on the Browse button below to select the directory/file name for the copy of alice.txt that is stored on your computer.

Choose File No file chosen

Once you have selected the file, click on the "Upload alice.txt file" button below. This will cause your browser to send a copy of alice.txt over an HTTP connection (using TCP) to the web server at gaia.cs.umass.edu. After clicking on the button, wait until a short message is displayed indicating the the upload is complete. Then stop your Wireshark packet sniffer - you're ready to begin analyzing the TCP transfer of alice.txt from your computer to gaia.cs.umass.edu!!

Upload alice.txt file

TCP: Capturing a bulk TCP transfer from your computer to a remote server

Upload page for TCP Wireshark Lab

Computer Networking: A Top Down Approach, 6th edition Copyright 2012 J.F. Kurose and K.W. Ross. All Rights Reserved

If you have followed the instructions for the TCP Wireshark Lab, you have already downloaded an ASCII copy of Alice and Wonderland from http://gaia.cs.umass.edu/wireshark-labs/alice.txt and you also already have the Wireshark packet sniffer running and capturing packets on your computer.

Click on the Browse button below to select the directory/file name for the copy of alice.txt that is stored on your computer

Choose File | No file chose

Once you have selected the file, click on the "Upload alice.txt file" button below. This will cause your browser to send a copy of alice.txt over an HTTP connection (using TCP) to the web server at gaia.cs.umass.edu. After clicking on the button, wait until a short message is displayed indicating the the upload is complete. Then stop your Wireshark packet sniffer - you're ready to begin analyzing the TCP transfer of alice.txt from your computer to gaia.cs.umass.edu!!

Upload alice.txt file

- 3. Use the "Choose File" button to choose the file on your computer containing Alice in Wonderland.
- 4. Start up Wireshark and begin packet capture.
- 5. Returning to your browser, press the "Upload alice.txt file" button to upload the file to the gaia.cs.umass.edu server.
- 6. Stop Wireshark packet capture.

Congratulations!

You've now transferred a copy of alice.txt from your computer to gaia.cs.umass.edu. You should now stop Wireshark packet capture. It's time to start analyzing the captured Wireshark packets!

TCP: A first look at the captured trace

[tcp	tcp							
No.	Time	Source	Destination	Protocol	Length Info			
	1 0.000000	10.79.156.252	52.204.186.195	TCP	66 62134 → 443 [SYN] Seq=0 Win=64240 Len=0 MSS=1460 WS=256 SACK_PERM			
	2 0.000055	34.199.110.211	10.79.156.252	TLSv1.2	108 Application Data			
	3 0.000216	10.79.156.252	34.199.110.211	TLSv1.2	1126 Application Data			
	4 0.215958	52.204.186.195	10.79.156.252	TCP	66 443 → 62134 [SYN, ACK] Seq=0 Ack=1 Win=26883 Len=0 MSS=1250 SACK_PERM WS=256			
	5 0.216009	10.79.156.252	52.204.186.195	TCP	54 62134 → 443 [ACK] Seq=1 Ack=1 Win=131072 Len=0			
	16 0.650570	52.204.186.195	10.79.156.252	TCP	54 443 → 62134 [ACK] Seq=148 Ack=1354 Win=30208 Len=0			
1	17 0.763488	10.79.156.252	204.79.197.200	TLSv1.2	3978 Application Data			
#	18 0.764083	10.79.156.252	204.79.197.200	TLSv1.2	3223 Application Data			

TCP: captured trace

The initial three-way handshake

		·		
1 0.000000	10.79.156.252	52.204.186.195	TCP	66 62134 → 443 [SYN] Seq=0 Win=64240 Len=0 MSS=1460 WS=256 SACK_PERM
2 0.000055	34.199.110.211	10.79.156.252	TLSv1.2	108 Application Data
3 0.000216	10.79.156.252	34.199.110.211	TLSv1.2	1126 Application Data
4 0.215958	52.204.186.195	10.79.156.252	TCP	66 443 → 62134 [SYN, ACK] Seq=0 Ack=1 Win=26883 Len=0 MSS=1250 SACK_PERM WS=256
5 0.216009	10.79.156.252	52.204.186.195	TCP	54 62134 → 443 [ACK] Seq=1 Ack=1 Win=131072 Len=0

Multiple TCP segments used to carry a single HTTP message

No		Time	Source	Destination	Protocol Lei	ngth Info
	1813	14.490980	92.223.85.120	10.79.156.252	TCP	66 [TCP Keep-Alive ACK] 443 → 55583 [ACK] Seq=1 Ack=2 Win=501 Len=0 SLE=1 SRE=2
	1814	15.403369	10.79.156.252	172.64.151.4	TCP	55 62049 → 443 [ACK] Seq=1 Ack=1 Win=510 Len=1 [TCP segment of a reassembled PDU]
	1815	15.407472	172.64.151.4	10.79.156.252	TCP	66 443 → 62049 [ACK] Seq=1 Ack=2 Win=8 Len=0 SLE=1 SRE=2
	1818	15.574390	10.79.156.252	13.224.163.73	TCP	55 62115 → 443 [ACK] Seq=1 Ack=1 Win=509 Len=1 [TCP segment of a reassembled PDU]
	1819	15.578807	13.224.163.73	10.79.156.252	TCP	66 443 → 62115 [ACK] Seq=1 Ack=2 Win=142 Len=0 SLE=1 SRE=2
	2242	15.995505	10.79.156.252	157.240.199.1	TLSv1.2	83 Application Data
	2243	16.000083	157.240.199.1	10.79.156.252	TCP	54 443 → 56110 [ACK] Seq=80 Ack=3464 Win=3160 Len=0
	2244	16.164945	157.240.199.1	10.79.156.252	TLSv1.2	79 Application Data
	2245	16.211861	10.79.156.252	157.240.199.1	TCP	54 56110 → 443 [ACK] Seq=3464 Ack=105 Win=510 Len=0
	2246	16.396873	10.79.156.252	52.1.247.29	TCP	55 62113 → 443 [ACK] Seq=1 Ack=1 Win=509 Len=1 [TCP segment of a reassembled PDU]
	2247	16.411704	10.79.156.252	44.218.89.127	TCP	55 62114 → 443 [ACK] Seq=1 Ack=1 Win=510 Len=1 [TCP segment of a reassembled PDU]
	2262	16.616800	52.1.247.29	10.79.156.252	TCP	66 443 → 62113 [ACK] Seq=1 Ack=2 Win=265 Len=0 SLE=1 SRE=2
	2263	16.628537	44.218.89.127	10.79.156.252	TCP	66 443 → 62114 [ACK] Seq=1 Ack=2 Win=122 Len=0 SLE=1 SRE=2
	2271	17.047320	10.79.156.252	52.111.234.0	TCP	55 61704 → 443 [ACK] Seq=1 Ack=1 Win=508 Len=1 [TCP segment of a reassembled PDU]
	2272	17.080711	52.111.234.0	10.79.156.252	TCP	66 443 → 61704 [ACK] Seq=1 Ack=2 Win=2047 Len=0 SLE=1 SRE=2
	2273	17.203475	10.79.156.252	52.111.240.8	TLSv1.2	89 Application Data
	2274	17.304533	52.111.240.8	10.79.156.252	TCP	54 443 → 61955 [ACK] Seq=1 Ack=36 Win=16386 Len=0

TCP: captured trace (Cont.)

HTTP POST message

```
2315 23.129719
                      10.79.156.252
                                                                            54 62135 → 80 [ACK] Seq=1 Ack=1 Win=131072 Len=0
                                            128.119.245.12
                                                                 TCP
   2316 23.132356
                      10.79.156.252
                                            128.119.245.12
                                                                         12554 POST /wireshark-labs/lab3-1-reply.htm HTTP/1.1
                                                                 HTTP
    2317 23.193741
                      157.240.199.60
                                            10.79.156.252
                                                                           126 Application Data
                                                                 TLSv1.2
   2318 23.234939
                      10.79.156.252
                                                                 TCP
                                                                            54 61336 → 443 [ACK] Seq=71 Ack=73 Win=510 Len=0
                                            157.240.199.60
                                                                            54 80 → 62135 [ACK] Seq=1 Ack=6251 Win=41728 Len=0
   2319 23.361489
                      128.119.245.12
                                            10.79.156.252
                                                                 TCP
> Frame 2316: 12554 bytes on wire (100432 bits), 12554 bytes captured (100432 bits) on interface \Devic \times
                                                                                                             0000 00 00 0c 07
                                                                                                                  00 00 4f 22
> Ethernet II, Src: Intel ed:56:5c (a4:6b:b6:ed:56:5c), Dst: All-HSRP-routers f1 (00:00:0c:07:ac:f1)
                                                                                                            0020 f5 0c f2 b7
> Internet Protocol Version 4, Src: 10.79.156.252, Dst: 128.119.245.12 client and server IPs
                                                                                                                  02 00 1c d6
Transmission Control Protocol, Src Port: 62135, Dst Port: 80, Seq: 1, Ack: 1, Len: 12500
                                                                                                                  73 68 61 72
     Source Port: 62135
                                                                                                             0050 31 2d 72 65
                              client and server port numbers
                                                                                                                  2f 31 2e 31
     Destination Port: 80
                                                                                                                  2e 63 73 2e
     [Stream index: 33]
                                                                                                            0080 73 65 72 2d
  > [Conversation completeness: Incomplete, DATA (15)]
                                                                                                                   6c 61 2f 35
     [TCP Segment Len: 12500]
                                                                                                                  4e 54 20 31
     Sequence Number: 1
                           (relative sequence number)
                                                                                                                  78 36 34 3b
                                                                                                                  65 63 6b 6f
     Sequence Number (raw): 2381331412
                                                                                                                  72 65 66 6f
     [Next Sequence Number: 12501
                                     (relative sequence number)]
                                                                                                                   65 70 74 3a
                                                                                                             00e0
     Acknowledgment Number: 1
                                 (relative ack number)
                                                                                                                  70 70 6c 69
                                                                                                             00f0
     Acknowledgment number (raw): 2547314748
                                                                                                                  2b 78 6d 6c
                                                                                                             0100
     0101 .... = Header Length: 20 bytes (5)
                                                                                                            0110
                                                                                                                  2f 78 6d 6c
                                                                                                                  2f 61 76 69
  > Flags: 0x010 (ACK)
     Window: 512
```

TCP: TCP Basics, 3-way handshake


```
Time
                                                            Protocol Length Info
                  Source
                                       Destination
                                                                       66 62134 → 443 [SYN] Seq=0 Win=64240 Len=0 MSS=1460 WS=256 SACK PERM
  1 0.000000
                  10.79.156.252
                                      52.204.186.195
                                                            TCP
                  34.199.110.211
                                       10.79.156.252
                                                            TLSv1.2 108 Application Data
  3 0.000216
                 10.79.156.252
                                       34.199.110.211
                                                            TLSv1.2 1126 Application Data
 4 0.215958
                 52.204.186.195
                                                                       66 443 → 62134 [SYN, ACK] Seq=0 Ack=1 Win=26883 Len=0 MSS=1250 SACK PERM WS=256
                                       10.79.156.252
                                                            TCP
  5 0.216009
                 10.79.156.252
                                       52.204.186.195
                                                            TCP
                                                                       54 62134 → 443 [ACK] Seq=1 Ack=1 Win=131072 Len=0
  6 0.216276
                 10.79.156.252
                                       52.204.186.195
                                                            TLSv1.2 371 Client Hello (SNI=capi.grammarly.com)
 7 0.259716
                 34.199.110.211
                                       10.79.156.252
                                                            TLSv1.2
                                                                      608 Application Data
 8 0.301592
                 10.79.156.252
                                       34.199.110.211
                                                            TCP
                                                                       54 62131 → 443 [ACK] Seq=1073 Ack=609 Win=507 Len=0
 13 0.432667
                 52.204.186.195
                                       10.79.156.252
                                                            TCP
                                                                       54 443 → 62134 [ACK] Seq=1 Ack=318 Win=28160 Len=0
                                                                      201 Server Hello, Change Cipher Spec, Encrypted Handshake Message
 14 0.432667
                 52.204.186.195
                                       10.79.156.252
                                                            TLSv1.2
 15 0.433925
                 10.79.156.252
                                       52.204.186.195
                                                            TLSv1.2 1090 Change Cipher Spec, Encrypted Handshake Message, Application Data
 16 0.650570
                 52.204.186.195
                                       10.79.156.252
                                                            TCP
                                                                       54 443 → 62134 [ACK] Seq=148 Ack=1354 Win=30208 Len=0
 17 0.763488
                 10.79.156.252
                                       204.79.197.200
                                                            TLSv1.2 3978 Application Data
 18 0.764083
                                       204.79.197.200
                                                            TLSv1.2 3223 Application Data
                 10.79.156.252
 19 0.764353
                 10.79.156.252
                                       204.79.197.200
                                                                       92 Application Data
                                                            TLSv1.2
 20 0.766830
                 204.79.197.200
                                       10.79.156.252
                                                            TCP
                                                                       54 443 → 62120 [ACK] Seq=1 Ack=2501 Win=16386 Len=0
                                                                                                       0000 00 00 0c 07 ac f1 a4 6b b6 ed 56 5c 08 00
Source Port: 62134
                                                                                                       0010 00 34 ca 8d 40 00 80 06 00 00 0a 4f 9c fc
Destination Port: 443
                                                                                                       0020 ba c3 f2 b6 01 bb 6c f3 f8 30 00 00 00 00
[Stream index: 0]
                                                                                                       0030 fa f0 97 01 00 00 02 04 05 b4 01 03 03 08
[Conversation completeness: Incomplete, DATA (15)]
                                                                                                       0040 04 02
[TCP Segment Len: 0]
Sequence Number: 0
                     (relative sequence number)
Sequence Number (raw): 1827928112
                            (relative sequence number)]
[Next Sequence Number: 1
Acknowledgment Number: 0
Acknowledgment number (raw): 0
1000 .... = Header Length: 32 bytes (8)
Flags: 0x002 (SYN)
Window: 64240
[Calculated window size: 64240]
[hecksum: 0x9701 [correct] (matches partial checksum, not 0x83ae, likely caused by "TCP checksum o
 Checksum Status: Good]
Urgent Pointer: 0
Options: (12 bytes), Maximum segment size, No-Operation (NOP), Window scale, No-Operation (NOP), No
> TCP Option - Maximum segment size: 1460 bytes
```

TCP: TCP Basics, 3-way handshake (Cont.)

```
1 0.000000
                 10.79.156.252
                                      52.204.186.195
                                                                      66 62134 → 443 [SYN] Seq=0 Win=64240 Len=0 MSS=1460 WS=256 SACK PERM
 2 0.000055
                 34.199.110.211
                                      10.79.156.252
                                                           TLSv1.2
                                                                    108 Application Data
 3 0.000216
                 10.79.156.252
                                      34.199.110.211
                                                           TLSv1.2 1126 Application Data
                                     10.79.156.252
                                                                      66 443 → 62134 [SYN, ACK] Seq=0 Ack=1 Win=26883 Len=0 MSS=1250 SACK_PERM WS=256
 4 0.215958
                 52.204.186.195
                                                           TCP
 5 0.216009
                                      52.204.186.195
                                                           TCP
                                                                     54 62134 → 443 [ACK] Seg=1 Ack=1 Win=131072 Len=0
                 10.79.156.252
 6 0.216276
                 10.79.156.252
                                      52.204.186.195
                                                           TLSv1.2 371 Client Hello (SNI=capi.grammarly.com)
                                                           TLSv1.2 608 Application Data
 7 0.259716
                 34.199.110.211
                                      10.79.156.252
 8 0.301592
                 10.79.156.252
                                      34.199.110.211
                                                          TCP
                                                                     54 62131 → 443 [ACK] Seq=1073 Ack=609 Win=507 Len=0
13 0.432667
                 52.204.186.195
                                      10.79.156.252
                                                                      54 443 → 62134 [ACK] Seq=1 Ack=318 Win=28160 Len=0
14 0.432667
                 52.204.186.195
                                      10.79.156.252
                                                          TLSv1.2 201 Server Hello, Change Cipher Spec, Encrypted Handshake Message
15 0.433925
                 10.79.156.252
                                      52.204.186.195
                                                           TLSv1.2 1090 Change Cipher Spec, Encrypted Handshake Message, Application Data
16 0.650570
                                                                      54 443 → 62134 [ACK] Seq=148 Ack=1354 Win=30208 Len=0
                 52.204.186.195
                                      10.79.156.252
17 0.763488
                 10.79.156.252
                                      204.79.197.200
                                                           TLSv1.2 3978 Application Data
18 0.764083
                 10.79.156.252
                                                           TLSv1.2 3223 Application Data
                                      204.79.197.200
19 0.764353
                 10.79.156.252
                                      204.79.197.200
                                                           TLSv1.2
                                                                     92 Application Data
20 0.766830
                                                           TCP
                                                                      54 443 → 62120 [ACK] Seq=1 Ack=2501 Win=16386 Len=0
                 204.79.197.200
                                      10.79.156.252
                                                                                                     0000 a4 6b b6 ed 56 5c 34 73 2d 93 c2 1f 08 00 45 00
Source Port: 443
                                                                                                     0010 00 34 00 00 40 00 de 06 05 e9 34 cc ba c3 0a 4f
Destination Port: 62134
                                                                                                     0020 9c fc 01 bb f2 b6 3f ec c4 fd 6c f3 f8 31 80 12
[Stream index: 0]
                                                                                                     0030 69 03 11 73 00 00 02 04 04 e2 01 01 04 02 01 03 i.s...
[Conversation completeness: Incomplete, DATA (15)]
[TCP Segment Len: 0]
Sequence Number: 0 (relative sequence number)
Sequence Number (raw): 1072481533
                           (relative sequence number)]
[Next Sequence Number: 1
Acknowledgment Number: 1
                           (relative ack number)
Acknowledgment number (raw): 1827928113
1000 .... = Header Length: 32 bytes (8)
Flags: 0x012 (SYN, ACK)
Window: 26883
[Calculated window size: 26883]
Checksum: 0x1173 [correct]
[Checksum Status: Good]
Urgent Pointer: 0
Options: (12 bytes), Maximum segment size, No-Operation (NOP), No-Operation (NOP), SACK permitted,
> TCP Option - Maximum segment size: 1250 bytes
```

TCP: Plot graphs


• Plot the RTT for each of the TCP segments sent in Wireshark: Select a TCP segment in the "listing of captured packets" window that is being sent from the client to the gaia.cs.umass.edu server. Then select Statistics->TCP Stream Graphs->Round Trip Time.



TCP: Plot graphs

• Plot the **Time-sequence graph** in Wireshark: Select
a TCP segment in the
Wireshark's "listing of
captured-packets" window.
Then select the menu:
Statistics->TCP Stream
Graphs-> Time-Sequence
(Stevens).







UDP: Review of UDP

- UDP: unreliable, unordered delivery
- Connectionless: No handshaking, each segment handled independently of others
- Checksum: detect errors in transmitted segment

UDP: UDP Basics



Wireshark: validate checksum if possible



Edit → Preferences → Protocols → TCP

Conclusion

- TCP
 - Review of TCP
 - Capturing a bulk TCP transfer from your computer to a remote server
 - A first look at the captured trace
 - TCP Basics: 3-way handshake, RTT
 - Plot graphs: RTT, Time-sequence Graph

- UDP
 - Review of UDP
 - UDP basics

Lab assignment: TCP and UDP

- The exercises will be posted on Canvas.
- For TCP, follow the instructions in 'Wireshark_TCP_v7.0' in section 2 (A first look at the captured trace) and answer the following questions: 1, 2, 3.
- For UDP, follow the instructions in 'Wireshark_UDP_v7.0' and answer the following questions: 3, 6.
- Submit a typed response with cropped screen captures to the above questions through Canvas.